

## Safety Instructions



Use domestic appliances with maximum power of 2,400W.



Connect the Kiwi Warmer to a socket-outlet with earthing connection.



Do not plug multiple devices, multiboxes, aquariums or health & safety-related devices into the Kiwi Warmer.



Always follow the appliance manufacturer's safety instructions.



Don't use the Kiwi Warmer in areas 2000m and more above sea level.

## Warranty

Kiwi Warmer's warranty against manufacturing or shipping faults lasts from 12 months from the purchase date. Please keep your receipt!

## Technical Support

support@kiwi-warmer.nz



**Kiwi  
Warmer**



## Quick Start Guide

Your new Kiwi Warmer turns power on and off to your appliances to maintain your desired room temperature and humidity.

You may set different Kiwi Warmers in different rooms, each with their own desired temperature and humidity, all managed from your mobile device.

- 1 Download the Kiwi Warmer app from the Apple or Google Play store.



- 2 Plug your Kiwi Warmer device into a wall socket.
- 3 Make sure your mobile device is connected to a 2.4 GHz WiFi network.
- 4 Start the app, select **Add new device**, and follow the app's instructions.

## About Kiwi Warmer

Kiwi Warmer governs each room's temperature and humidity in your home, minimising wasted energy while optimising comfort.

You can set, adjust and monitor Kiwi Warmer-enabled rooms from your mobile device. Kiwi Warmer works with Heaters, Coolers, Humidifiers and Dehumidifiers.

Your privacy and security is important to us. For Privacy Policy please visit [www.kiwi-warmer.nz/privacy-policy.html](http://www.kiwi-warmer.nz/privacy-policy.html)


### To reset a Kiwi Warmer:

- 1 Unplug the Kiwi Warmer from the wall socket.
- 2 Hold the Setup button in as you plug it back in – wait for the blue status light, then release.
- 3 The Kiwi Warmer restarts with a blue status light.

## Kiwi Warmer Manual

For the full operator's manual, please visit [www.kiwi-warmer.co.nz/support/](http://www.kiwi-warmer.co.nz/support/)

- 1 Status lights and Setup Button
- 2 Sensor on wire
- 3 Domestic appliances (under 2,400W)



### Status Lights

- Not set up
- Set up mode
- Up and running (no power)
- Up and running (heating)
- Updating settings
- Error

**Red light?** Please check if the sensor is plugged in correctly and make sure Kiwi Warmer is connected to WiFi.

Please ensure:

- 1 You have a permanent WiFi connection (2.4 GHz 802.11b/g/n).
- 2 The built-in timers and regulators of appliances are turned off.
- 3 The sensor is plugged into your Kiwi Warmer.